



Great Rates Australia

Caravan hire

Jayco Eagle - Detailed Setup/Set Down Instructions

Setup

Caravan Starts on Jockey Wheel

- 1 Stop car, turn off car and connect Jockey Wheel from the front storage container of the caravan
- 3 Use Jockey wheel to lift the caravan off the ball of the car.
- 4 Put on the Hand Brake - pull on hard
- 5 Release D-Shackles
- 6 Undo the electrical cables between can & Caravan
- 7 Once all connections are released, move the car away
- 8 Use the jockey wheel to level caravan as best as possible.
- 9 Lower feet winders and tighten until finger tight

- 1 Move onto opening the lid of the caravan
- 2 Undo all four side latches
- 3 If you want to use the awning, suggest opening now
- 4 Connect winding tool out of front hatch into inlet at rear of caravan
- 6 Double check all four latches are down
- 7 Start winding up - note to watch the tensioner/Height gauge cable
- 8 Stop at about 2 inches up to ensure all four corners are going up equally

- 10 Wind to 100% - the green cable will have a little tension
- 11 Never extend the roof beyond the height gauge cable being tight
- 12 Pull out the door step
- 13 Pull out rear bed, never put downward pressure until stabilisers are in
- 14 Sometimes this can be sticky - may need a little wiggle, ensure it is drawn all the way out

15	Gather the roof support pole from under rear mattress, put near the green cable on the rear left side to hold up roof in case of failure
16	Install the bed end support bars and use shoulder to raise the bed. Support bars are under the mattress and circular end goes into the triangle section under the van
17	Pull canvas around the bed end frame - just loose for now
18	Pull out front bed, never put downward pressure until stabilisers are in
19	If sticky - ensure the sliders are free of canvas
20	Gather the roof support from under front bed, put on the front right corner near the riser
21	Grab support bars from under the mattress and install the bed end support bars and use shoulder to raise the bed. End of pole goes into vertical bars on A Frame
22	Put the canvas around the bed end frame - loose for now
1	If required - place foot support behind tyres
2	Suggest connecting to mains power now using the 15A provided cable
3	Open the door by pressing in the button - if locked use silver key with circular end
4	Go inside
6	Isolation switch - turn on
7	Sit up the cupboard lying down towards back bed & use internal lock in the cupboard to lock in place
8	Grab bucket with cleaning materials from under rear central couch
9	Move central couch sections from on the front central couch to the rear central couch
10	Inside - Prop up bed ends canvas with support bars (hockey stick) under the mattress on each end, slots into spot above head
11	Hockey stick circular end goes into circular section in middle of the bar over the matters
12	Tight fit - use two hands to push the pole into slot
1	Go back outside and wrap around the 4 corner velcro covers around the corner support bars
2	Strap down velcro on both bed ends - pull tight around bed ends
3	Next head back in and remove the plastic over door and put plastic under front mattress, unclip the door from the roof
4	Guide into pins on the top of the door frame at bottom and push into the top
5	Use little clips at top to secure in place with frame
6	Unclip side clips on door - note this can be used for additional security
7	Connect top to bottom section using vertical clip
8	Use the velcro strips to secure both side doors - top and sides, inside & outside
11	Extra Bed 1 - Front bed is easy - board slots in between existing cushions & extra cushion goes on top
12	Extra Bed 2 - Middle bed - lift up the table, clip leg into table, unclip table from wall with 2x clips. Slots in between the two middle couches & ends of couches become part of bed
1	Next unroll the awning & setup poles

2	End pole should be in the awning already, roll out awning.
3	Setup anti-flapping system along sides of awning
4	Setup 2x vertical poles and connect to horizontal pole
	Set Down
1	To set down - explain to take out all personal items first
2	Turn off the gas
3	Shut off isolation switch
4	Take the rear central couch cushions out and place on the front central cushions
5	Take out the internal bed roof supports & drag in the canvas so it sits in middle of the bed as best as possible
6	Open the tall cupboard and unpin the cupboard using the gold pin, lie it back down
7	Turn the water tap into the sink and ensure the board is over the sink & the microwave plate is in the sink with hand towels
8	Move onto the door, undo velcro on sides and top, unclip at top, secure clips on the left side, undo vertical clip in middle of door
9	Take plastic sheet from under front mattress and put over the door now on the ceiling
10	Move outside, undo the velcro around the bed ends and push the canvas into the bed as best as possible
11	Go back inside, pull in the canvas on the ends into the middle of the bed, do another check to make sure nothing is sticking up or left inside
12	Back outside, push the mattresses as far forward as possible while staying on the bed frame
13	Take out the roof support poles at front left and back right corners and put alongside the mattresses
1	Take out the bed end poles & place under mattresses on each end
2	Roll in the beds - be gentle with them, ensure canvas is not being caught
3	SLOWLY wind down the roof, take note to push in canvas as the roof comes down otherwise it will not shut
4	Stop 1- at half way, walk around and push in canvas
5	Stop 2 - at 3/4 down, walk around and push in canvas
6	Stop 3 - with around 7-10 cm to go, walk around and push in canvas again - check that front bed frame is not impacting roof
7	Once all the way down, rotate twice more once slack. If ends are not quite down, ensure nothing hard is fouling it, otherwise use a little force to push down.
8	Once all the way down and snug in all four corners, make sure no canvas is sticking out
9	Clip in all four corner clips
10	Return to the winder tool, tighten tool until slightly resistance is felt - this protects the cabling
11	Put winder tool back in front of van
12	Wind up the corner steadies on all four sides, front steadies must point backwards
13	Lift up the front of the van using the jockey wheel
14	Hitch to car - test connection, clip should be in the hole to stop it releasing from the ball

15	Connect metal chains to car - crossed
16	Remove jockey wheel and put in car or front of caravan
17	Take off Hand brake
18	Connect electric brake unit & cables to car
19	Any time you turn off the engine, always check the connection to the car
20	Check brakes, indicators